




KitchenAid Professional 600 Bevel Gear Replacement

The Bevel gear works with the Worm gear to rotate the spindles attached to the mixer.

Written By: Luke





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [Snap Ring Pliers](#) (1)
-

Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

Step 2




- Remove the four Phillips #2 screws located around the mixer where the band was removed.
- ⓘ This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

Step 3




- Remove the top of the mixer to reveal the inner parts.

Step 4 — Gear Housing Cover





- Remove the 4 Phillips #2 screws connecting the black housing cover to the device.
- ⓘ Only one of the screws is seen in the picture. The other three are also located around the black housing cover.

Step 5




- Take off the black housing cover.

Step 6 — Bevel Gear



- To remove the Bevel Gear, remove the snap ring wrapped around the base of the gear using Snap Ring pliers.

Step 7



- Slide the Bevel Gear off.
- ⓘ Remember to apply food safe grease onto your new replacement part before assembling the device back together.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 11:08:43 AM.